Fuel - Blinking white LED, system power cycles or reboots on its own.

Published 08/23/2002

Symptom(s):

Fans running
Blinking white LED
system power cycles or reboots on its own.

Fact(s):

Silicon Graphics Fuel

SGI Solution:

This behavior is normal during a system power on or power off, however, if the system is shutting down with no apparent reason there might be a hardware issue.

Reseat power supply and its connections, remove the front plastic cover while debugging to make sure the problem is not caused by the font bezel. If problem continues, replace power supply first, if problem goes away, inspect the front bezel power button, it might need to be replaced.

Cause(s):

Power button pressed (On or Off)

Answers others found helpful

- How-to lock the Ethernet Interface to 100mbit/full duplex on a Fuel

Additional Details

Creation Date	02/05/2002 04:25 AM
Last modification	01/15/2016 04:29 PM
Published Date	08/23/2002
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution